



Nuova Rade

Marine - Plastics Technology Experts

Installation Instructions for 44813 Lock *TOP LINE / MID LINE / CLASSIC / KROME HATCHES*

The Nuova Rade TOP LINE / MID LINE / CLASSIC / KROME hatches can become lockable by having the 44813 lock installed in the handle cavity, as shown in Picture 1.

To make this conversion, you will need:

- The TOP LINE / MID LINE / CLASSIC / KROME hatch.
- One Nuova Rade 44813 lock (Picture 2).
- Ø12mm drill.
- Silicone (without benzene, acetone etc).



Picture 1

Lock 44813 installed



Picture 2

Lock 44813 and Keys for Hatch



Picture 3

"OPEN" Latch position and
drilling point (red dot)



Picture 4

"CLOSED" Latch position.
(The blue dot is the lock pin passing
through the latch hole)

Instructions

- Place the hatch lid facing backside up.
- Turn the latch as shown in Picture 3.
- Find the drilling point, indicated on the hatch with a dimple (also marked in red in Picture 3).
- Drill a Ø12mm hole.
- Screw the 44813 lock into the hole drilled and seal it with silicone, to make it watertight.
- Leave the silicone to dry.
- To lock the hatch: **Bring latch to "closed" position (picture 4) and push the lock button.**