

Manual for Diablo Easy Switch Plates

Code: 197487-91



197487 Easy switch



197488 Easy switch fresh water



Easy switch waste water h230



Easy switch waste water h305



197490 Easy switch blind

In order for the tank to be closed, the switch plate must close tight to avoid leakage.

The lid must get through all the holes in order to close properly. The "ear" must get through all holes, even the last one (see Picture 1, Picture 2).





There is a possibility that the Diablo Switch Plates would become a little difficult while closing them, as the gasket is quite hard and, also, has a slightly bigger design, that prevents it from dropping out from its position. In such case, a usage of a wooden stick or a metal lever, positioned in the way seen at the following images. is highly recommended.









